


NEBO[®]

SLYDE KING™ 4K



The Slide King™ 4K combines a high-powered 4000 lumen flashlight, 1000 lumen work light and a strong magnetic base for hands-free use.




4X ADJUSTABLE ZOOM



WATERPROOF 1 METER · 30 MIN



AIRCRAFT GRADE ALUMINUM



MAGNETIC BASE



USB-C RECHARGEABLE

Fully recharge in as little as 4 hours.



USB-C



USB-A



CHARGING INSTRUCTIONS

Insert the USB-C end of the included charging cable into the USB-C port on the flashlight. Next, insert the USB-A end of the charging cable into a power source with a USB-A port.

WHEN CHARGING



The power button light serves as the charging status indicator.



Solid Green: Battery is charged



Pulsing Green: Battery is charging

BATTERY LEVEL INDICATOR



The power button light serves as the battery level indicator while the product is in use (any mode).



Steady Orange: Battery more than 25%




Pulsing Orange: Battery less than 25%



FLASHLIGHT

Light up the night with 400 to 4000 lumens to see near or far.



FLASHLIGHT OPERATION

POWER SELECT

Press the power button to turn on light. Press again to turn off light.

BRIGHTNESS/DIMMING

Lights have continuous dimming and brightening cycling with memory.

When ON, press and hold power button to activate dimming; release to set desired brightness.

Double-tap from off to activate dimmed flashlight mode.

4X ZOOM

Twist the head of the light to adjust the light beam from flood light to spot light.




WORK LIGHT

Dimmable control between 100 to 1000 lumens.



RED MODE

Preserve your night vision with direct-to-red or switch to the hazard flasher for emergencies.



WORK LIGHT OPERATION

MODE SELECT

Slide open to activate the work light. Press and release power button to switch between White, Red, and Flash modes.

DIRECT-TO-RED

Press and hold power button while sliding the work light open.

BRIGHTNESS/DIMMING

Lights have continuous dimming and brightening cycling with memory.

When ON, press and hold power button to activate dimming; release to set desired brightness.

Double-tap to activate dimmed work light mode.

MODES	OUTPUT (Lumens)	RUN TIME (Hours)	BEAM DISTANCE (Meters/Yards)
FLASHLIGHT HIGH	4000	1	350 / 382
FLASHLIGHT LOW*	400	6	100 / 109
WORK LIGHT HIGH	1000	4	35 / 38
WORK LIGHT LOW*	100	24	10 / 10
RED LIGHT HIGH	40	6	-
RED LIGHT LOW*	-	35	-
RED STROBE	-	-	-

*Low modes are activated via the dimming function

PRODUCT GUARANTEE

If you experience a problem, please do not return to your local store. Contact our Customer Service team at 800-255-6061 or NEBOLIGHTS.com

For more information, detailed video instructions, and warranty registration, visit NEBOLIGHTS.com